

Instructions for A40403-021

The Ice Deflector is hooked to the bottom of the Ice Chute To Install the Deflector:

1. Switch unit off (Red Button)
2. Remove front panel.
3. Push bail clamp back
4. Remove ice sweep
5. Lift top chute.
6. Remove eyes and vertical chute. Set aside.
7. Install stainless steel deflector on the lip next to the chute gasket
8. Reinstall vertical chute in opening it will have a tight fit for no wobble effect.
9. Install eyes. Make sure the eyes are in the proper position and have not moved out of position. The photo eyes must be aligned through the hole in the ice chute to sense the ice. They snap into the correct position.
10. Reassemble top chute to evaporator.
11. Install ice sweep, chute cover and bail clamp.
12. Place front panel on unit.
13. Switch unit on (Green Button). Ice will now be deflected towards the back of the dispenser.

